


NSX-AJ17 UNSX-BL14



SERVICE MANUAL

COMPACT DISC STEREO CASSETTE RECEIVER

BASIC TAPE MECHANISM : ZZM-2 PR1NM BASIC CD MECHANISM : AZG-1 ZA3RDM, AZG-1 ZA3RNDM

SYSTEM	CD CASSEIVER	CD MECHANISM	SPEAKER	REMOTE CONTROLLER
NSX-AJ17	CX-NAJ17	AZG-1 ZA3RDM	SX-NAJ17	RC-ZAS02
NSX-BL14	CX-NBL14	AZG-1 ZA3RNDM	SX-NBL17	NO-ZA302

- This Service Manual is the "Revision Publishing" and replaces "Simple Manual" NSX-AJ17(U)/BL14(LH), (S/M Code No. 09-001-428-8T1).
- If requiring information about the CD mechanism, see Service Manual of AZG-1, (S/M Code No. 09-001-335-3NC).



REVISION DEED

SPECIFICATIONS

<FM tuner section>

Tuning range 87.5 MHz to 108 MHz

Usable sensitivity (IHF) 13.2 dBf

Antenna terminals 75 ohms (unbalanced)

<AM tuner section>

Tuning range 530 kHz to 1710 kHz (10 kHz step)

531 kHz to 1602 kHz (9 kHz step)

Usable sensitivity 350 μV/m Loop antenna Antenna

<Amplifier section>

Power output Rated

U: 30 W + 30 W (50 Hz - 20 kHz, THD less than 1%, 6 ohms) LH: 28 W + 28 W (1 kHz. THD 1%. 6 ohms)

Reference

U: 40 W + 40 W (1 kHz, THD less

than 10%, 6 ohms)

LH: 35 W + 35 W (1 kHz, THD 10%

6 ohms)

Total harmonic distortion U: 0.1% (15 W, 1 kHz, 6 ohms,

DIN AUDIO)

LH: 0.1% (14 W, 1 kHz, 6 ohms,

DIN AUDIO)

Inputs VIDEO/AUX: 500 mV

Outputs SPEAKERS: accept speakers of 6

ohms or more

SURROUND SPEAKERS <U>

accept speakers of 8 ohms to 16

ohms

PHONES (stereo jack): accepts headphones of 32 ohms or more

<Cassette deck section>

Track format 4 tracks, 2 channels stereo

Frequency response 50 Hz - 8000 Hz Recording system AC bias

Deck 1: Recording/Playback head Heads

> x 1, erase head x 1 Deck 2: Playback head x 1

<Compact disc player section>

Laser Semiconductor laser (λ =780 nm)

D-A converter 1 bit dual

Signal-to-noise ratio 85 dB (1 kHz, 0 dB) Harmonic distortion 0.05 % (1 kHz, 0 dB) <Speaker system>SX-NAJ17<U>

Speaker System 2 way, bass reflex (magnetic

shielded type)

Speaker units Woofer: 120 mm (43/4 in.) cone type

Tweeter:

20mm (13/16 in.) cone type

Impedance 6 ohms Sensitivity 86 dB/W/m

Dimensions (W x H x D) 220 x 324x 211 mm (83/4 x 127/8 x 83/8 in.)

Weight 2.0 kg (4 lbs 7 oz.)

<Speaker system>SX-NBL17<LH>

Speaker System 2 way, bass reflex (magnetic

shielded type) Speaker units Woofer:

120 mm cone type

Tweeter: 20mm cone type 6 ohms

Impedance 87 dB/W/m Sensitivity Dimensions (W x H x D)

220 x 324x 211 mm

Weight 2.0 kg

<General>

Power requirements U: 120 V AC. 60 Hz

LH: 120 V/220-230 V/240 V AC

(switchable), 50/60 Hz

U: 60 W **Power consumption** LH: 55 W

With power-economizing Power consumption

in standby mode mode off: 12 W

With power-economizing

mode on: 0.9 W

Dimensions of main unit

260 x 330 x 348 mm $(W \times H \times D)$

(10¹/₄ X 13 X 13³/₄ in.) LH: 260 x 324 x 348 mm

Weight of main unit U: 5.7 kg (12 lbs 9 oz.)

LH: 5.7 kg

[•] Design and specifications are subject to change without notice.

PROTECTION OF EYES FROM LASER BEAM DURING SERVICING

This set employs laser. Therefore, be sure to follow carefully the instructions below when servicing.

WARNING!!

WHEN SERVICING, DO NOT APPROACH THE LASER EXIT WITH THE EYE TOO CLOSELY. IN CASE IT IS NECESSARY TO CONFIRM LASER BEAM EMISSION. BE SURE TO OBSERVE FROM A DISTANCE OF MORE THAN 30cm FROM THE SURFACE OF THE OBJECTIVE LENS ON THE OPTICAL PICK-UP BLOCK.



- Caution: Invisible laser radiation when open and interlocks defeated avoid exposure to beam.
 - Advarsel: Usynlig laserståling ved åbning, når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling.

VAROITUS!

Laiteen Käyttäminen muulla kuin tässä käyttöohjeessa mainitulla tavalla saattaa altistaa käyt-täjän turvallisuusluokan 1 ylittävälle näkymättömälle lasersäteilylle.

VARNING!

Om apparaten används på annat sätt än vad som specificeras i denna bruksanvising, kan användaren utsättas för osynling laserstrålning, som överskrider gränsen för laserklass 1.

CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

ATTENTION

L'utillisation de commandes, réglages ou procédures autres que ceux spécifiés peut entraîner une dangereuse exposition aux radiations.

ADVARSEL

Usynlig laserståling ved åbning, når sikkerhedsafbrydereer ude af funktion. Undgå udsættelse for stråling.

This Compact Disc player is classified as a CLASS 1 LASER product.

The CLASS 1 LASER PRODUCT label is located on the rear exterior.

CLASS 1 LASER PRODUCT
KLASSE 1 LASER PRODUKT
LUOKAN 1 LASER LAITE
KLASS 1 LASER APPARAT


Precaution to replace Optical block

(KSS-213F)

Body or clothes electrostatic potential could ruin laser diode in the optical block. Be sure ground body and workbench, and use care the clothes do not touch the diode.

 After the connection, remove solder shown in right figure.





NOTE ON BEFORE STARTING REPAIR


1. Forced discharge of electrolytic capacitor of power supply block

When repair is going to be attempted in the set that uses relay circuit in the power supply block, electric potential is kept charged across the electrolytic capacitors (C101, 102) even though AC power cord is removed. If repair is attempted in this condition, secondary defect can occur.

In order to prevent the secondary trouble, perform the following measures before starting repair work.

Discharge procedure

- **1** Remove the AC power cord.
- 2 Connect a discharging resistor at an end of lead wire that has clips at both ends. Connect the other end of the lead wire to metal chassis.
- **3** Contact the other end of the discharging resistor to the positive (+) side (+VH) of C101. (For two seconds)
- ② Contact the same end of the discharging resistor as step ③ to the negative (-) side (-VH) of C102 in the same way. (For two seconds)
- Check that voltage across C101 and C102 has decreased to 1 V or less using a multimeter or an oscilloscope.



Select a discharging resistor referring to the following table.

Fig-1

Charging voltage (V) (C101, 102)	Discharging resistor (Ω)	Rated power (W)	Parts number
25-48	100	3	87-A00-247-090
49-140	220	5	87-A00-232-090

Note: The reference numbers (C101, C102) of the electrolytic capacitors can change depending on the models. Be sure to check the reference numbers of the charging capacitors on schematic diagram before starting the discharging work.

2. Check items before exchanging the MICROCOMPUTER

Be sure to check the following items before exchanging the MICROCOMPUTER. Exchange the MICROCOMPUTER after confirming that the MICROCOMPUTER is surely defective.

2-1. Regarding the HOLD terminal of the MICROCOMPUTER

When the HOLD terminal (INPUT) of the MICROCOMPUTER is "H", the MICROCOMPUTER is judged to be operating correctly. When this terminal is "L", the main power cannot be turned on. Therefore, be sure to check the terminal voltage of the HOLD terminal before exchange.

When the MICROCOMPUTER is not defective, the HOLD terminal can also go "L" when the POWER AMPLIFIER has any abnormalities that triggers the abnormality detection circuit on the MAIN C. B. that sets the HOLD terminal to "L".

Good or no good judgement of the MICROCOMPUTER

- 1 Turn on the AC main power.
- ② Confirm that the main power is turned on and the HOLD terminal of the MICROCOMPUTER keeps the "H" level or not.
- When the HOLD terminal is "L" level, the abnormality detection circuit is judged to be working correctly and the MICROCOMPUTER is judged to be good.




Fig-2-1

In such a case, check also if the POWER AMPLIFIER circuit or power supply circuit has any abnormalities or not.

2-2. Regarding reset

There are cases that the machine does not work correctly because the MICROCOMPUTER is not reset even though the AC power cord is re-inserted, or the software reset (pressing the STOP key + POWER key) is performed.

When the above described phenomenon occurs, it can lead to wrong judgement as if the MICROCOMPUTER is defective and to exchange the MICROCOMPUTER. In such a case, perform the forced-reset by the following procedure and check good or no good of the MICROCOMPUTER.

1 Remove the AC power cord.




Fig-2-2

- ② Short both ends of the electrolytic capacitor C113 that is connected to VDD of the MICROCOMPUTER with tweezers.
- 3 Connect the AC power cord again. If the MICROCOMPUTER returns to the normal operation, the MICROCOMPUTER is good.

Note: The reference number or MICROCOMPUTER pin number of transistor (Q110) and electrolytic capacitor (C113) can change depending on the models. Be sure to check the reference numbers on schematic diagram before starting the discharging work.

2-3. Confirmation of soldering state of MICROCOMPUTER

Check the soldering state of the MICROCOMPUTER in addition to the above described procedures. Be sure to exchange the MICROCOMPUTER after surely confirming that the trouble is not caused by poor soldering but the MICROCOMPUTER itself.

ELECTRICAL MAIN PARTS LIST


REF. NO.	PART NO.	KANRI NO.	DESCRIPTION	REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
IC				C36	87-010-381-080	CAP, E	LECT 330-16V
				C38	87-A11-567-080		S 0.01-50 K B
	8A-NFA-615-010	,	8B57MCH-E236FP	C60	87-010-403-080		LECT 3.3-50V
	87-A21-397-010	IC,STK4		C97	87-010-196-080		APACITOR, 0.1-25
	87-A21-629-010 87-A21-419-040		442-1-N M14558MD-TE2	C100	87-018-127-080	CAP TC	-U 470P
	87-A21-413-040		2495AFP	C101	87-010-183-080	C-CAP.	S 2700P-50 B
	0, 1121 110 010	0 10/110	2 13 5111 1	C102	87-010-183-080		S 2700P-50 B
	87-A21-415-010	IC,LA18	43	C103	87-010-545-080		LECT 0.22-50V
	87-070-127-110	IC,LC72	131 D	C104	87-010-545-080		LECT 0.22-50V
				C105	87-010-178-080	CHIP CA	AP 1000P
TRANSISTO	2			C106	87-010-178-080	CHIP C	AP 1000P
				C107	87-010-404-080		LECT 4.7-50V
	87-026-609-080			C108	87-010-404-080		LECT 4.7-50V
	89-213-702-010		370 (1.8W)	C111	87-010-391-080		10-35 SME
	87-026-610-080 87-A30-076-080			C112	87-010-391-080	CAP, E.	10-35 SME
	87-A30-075-080			C113	87-010-405-080	CAP, E	LECT 10-50V
				C114	87-010-405-080		LECT 10-50V
	87-026-245-080		14ES <lh></lh>	C119	87-010-197-080		HIP 0.01 DM
	87-A30-198-080		199GR <lh></lh>	C120	87-010-197-080		HIP 0.01 DM S 0.1-50 F
	87-A30-090-080 87-A30-484-080			C125	87-012-368-080	C-CAP,	5 U.1-5U F
	87-A30-468-080		C102S-RTK	C126	87-012-368-080	C-CAP,	S 0.1-50 F
				C127	87-012-368-080		S 0.1-50 F
	87-A30-107-070			C128	87-012-368-080		S 0.1-50 F
	87-A30-106-040	,		C129	87-A11-572-080	,	S 0.015-50 K B
	87-A30-091-080 87-A30-062-080	FET,2SJ C-TR,KF		C130	87-A11-572-080	C-CAP,	S 0.015-50 K B
	87-A30-318-080			C131	87-010-197-080	CAP, CI	HIP 0.01 DM
				C132	87-010-197-080		HIP 0.01 DM
	89-333-317-880		331 (0.5W)	C133	87-010-186-080		IP 4700P
	87-A30-234-080 89-327-143-080		115BC 714 (0.1W)	C140 C183	87-010-182-080 87-010-387-080		S 2200P-50 B 470-25 SME <u></u>
	87-A30-489-080			C103	07-010-307-000	CAF,E	470-25 SME(0)
		,		C200	87-018-195-080	CAP TC	-U 1200P
				C235	87-010-408-080		LECT 47-50V <u></u>
DIODE				C236	87-010-408-080		LECT 47-50V <u></u>
	87-020-465-080	DIODE 1	SS133 (110MA)	C300 C301	87-018-195-080 87-010-179-080		-U 1200P IP S B1200P
	87-A40-393-090		N5402GW (F20) <u></u>	C301	07 010 175 000	CAI , CII.	II B BIZUUI
	87-A40-455-080		L203 GW	C302	87-010-179-080	CAP, CH	IP S B1200P
	87-A40-553-080		N4003 LES	C303	87-010-178-080		AP 1000P
	87-A40-774-080	ZENER, U	Z24BSD	C304 C305	87-010-178-080 87-010-198-080		AP 1000P HIP 0.022
	87-A40-764-080	ZENER, U	Z10BSC	C307	87-010-158-080		LECT 100-10V
	87-A40-313-080		,MC 2840			,	
	87-A40-270-080		,MC2838	C308	87-010-263-080	,	LECT 100-10V
	87-A40-269-080		, MC2836	C311	87-010-598-080		S 0.068-16VRK S 0.068-16VRK
	87-A40-768-080	ZENER, U	Z10B5A	C312 C313	87-010-598-080 87-010-188-080	,	IP 6800P
	87-A40-752-080	ZENER, U	Z6.2BSC	C314	87-010-188-080		IP 6800P
	87-A40-739-080		Z2.7BSA				
	87-017-149-080	ZENER, H	ZS6A2L	C315	87-010-263-080		LECT 100-10V
				C317 C318	87-010-546-080 87-010-546-080		LECT 0.33-50V LECT 0.33-50V
MAIN C.B				C326	87-010-340-080		HIP 0.022
				C327	87-010-196-080		APACITOR, 0.1-25
C3	87-010-196-080		PACITOR, 0.1-25	G2.53	08 010 401 201	63.5	T DOD 1 50**
C4 C5	87-010-196-080 87-010-196-080		PACITOR, 0.1-25 PACITOR, 0.1-25	C360 C399	87-010-401-080 87-012-140-080	,	LECT 1-50V
C6	87-010-196-080		PACITOR, 0.1-25	C401	87-012-140-080		LECT 0.1-50V
C9	87-010-196-080		PACITOR, 0.1-25	C402	87-010-544-080		LECT 0.1-50V
				C405	87-010-197-080	CAP, CI	HIP 0.01 DM
C10 C11	87-010-196-080		PACITOR, 0.1-25	C406	07 010 107 000	מאים מו	IIID 0 01 DM
C11	87-010-196-080 87-010-196-080		PACITOR, 0.1-25 PACITOR, 0.1-25	C406 C407	87-010-197-080 87-010-197-080		HIP 0.01 DM HIP 0.01 DM
C19	87-A10-627-000		200-50 M SMG	C408	87-010-197-080		HIP 0.01 DM
C20	87-A10-627-000	CAP,E 2	200-50 M SMG	C409	87-010-182-080	C-CAP,	S 2200P-50 B
G01	07 016 405 000	01 P = 2	200 25 M CMC	C410	87-010-182-080	C-CAP,	S 2200P-50 B
C21 C22	87-016-495-000 87-016-495-000	,	300-25 M SMG 300-25 M SMG	C411	87-010-405-080	מאָר)	LECT 10-50V
C25	87-010-385-080		ECT 220-25V	C412	87-010-405-080		LECT 10-50V
C26	87-010-247-080	CAP, EI	ECT 100-50V	C452	87-010-382-080	CAP, E	LECT 22-25V
C30	87-010-247-080	CAP, EI	ECT 100-50V	C453	87-010-183-080		S 2700P-50 B
C31	87-010-263-080	ריא ס אי	ECT 100-10V	C454	87-010-183-080	C-CAP,	S 2700P-50 B
C31	87-010-263-080		IP 0.01 DM	C455	87-010-183-080	C-CAP.	S 2700P-50 B
C33	87-010-263-080		ECT 100-10V <u></u>	C456	87-010-197-080		HIP 0.01 DM
C34	87-010-247-080		ECT 100-50V	C460	87-010-196-080		APACITOR, 0.1-25
C35	87-010-406-080	CAP, EI	ECT 22-50	C461 C462	87-012-158-080 87-012-158-080		S 390P-50 CH S 390P-50 CH
				C40Z	01-017-120-080	C-CAP,	3 330F-30 CA


REF. NO		KANRI NO.	DESCRIPTION		PART NO.	KANRI NO.	DESCRIPTION
C605 C606 C609 C610 C611	87-010-179-080 87-010-179-080 87-010-213-080 87-010-213-080 87-010-545-080	CAP, CHIF CAP, CHIF C-CAP, S C-CAP, S	S B1200P S B1200P 0.015-50 B 0.015-50 B CT 0.22-50V	C987 C993 C995 C997 C999	87-010-197-080 87-010-178-080 87-010-178-080 87-010-196-080 87-A11-155-080	CAP, CHIP CHIP CHIP	CHIP 0.01 DM CAP 1000P CAP 1000P CAPACITOR,0.1-25 CC U 0.01-16 Z F
C612 C613 C614 C615 C616	87-010-545-080 87-010-545-080 87-010-545-080 87-010-154-080 87-010-385-080	CAP, ELE CAP, ELE CAP CHIF	CT 0.22-50V CT 0.22-50V	CF831 CF832 CN301 CN351 CN601	87-008-261-010 87-008-261-010 87-A60-620-010 87-A60-625-010 87-099-719-010	FILTE CONN, CONN,	ER, SFE10.7MA5-A ER, SFE10.7MA5-A 3P V 2MM JMT 8P V 2MM JMT 30P TYK-B(X)
C617 C618 C630 C669 C670	87-010-385-080 87-010-405-080 87-016-669-080 87-010-322-080 87-010-322-080	CAP, ELE C-CAP,S C-CAP,S	CT 220-25V CT 10-50V 0.1-25 K B 100P-50 CH 100P-50 CH	CN602 CNA1 FFE831 J101 J203	87-099-194-010 8A-NF8-653-010 A8-8ZA-190-030 87-A60-602-010 87-A60-238-010	CONN 8ZA-1 JACK,	.6P 6216V ASSY,9P TID-A(480) <lh> L FEUNM .DIA6.3 BLK ST W/SW TC INAL,SP 4P (MSC)</lh>
C677 C771 C772 C782 C783	87-010-197-080 87-010-263-080 87-010-197-080 87-010-197-080 87-010-197-080	CAP, ELE CAP, CHI CAP, CHI	P 0.01 DM CT 100-10V P 0.01 DM P 0.01 DM P 0.01 DM	J205 J602 J831 L101 L102	87-A60-881-010 87-A60-881-010 87-A60-202-010 87-003-383-010 87-003-383-010	JACK, TERMI COIL,	PIN 2P MSP 242V05 PBSN <u> PIN 2P MSP 242V05 PBSN INAL,ANT 4P MSP-154V-02 1UH-S 1UH-S</u>
C784 C785 C786 C788 C789	87-010-197-080 87-010-197-080 87-010-197-080 87-010-149-080 87-A12-052-080	CAP, CHI CAP, CHI C-CAP,S	P 0.01 DM P 0.01 DM P 0.01 DM 5P-50 CH 0.033-25 J B	L451 L801 L802 L811 L832	87-007-342-010 87-A50-540-010 87-A91-551-010 87-005-847-080 87-005-847-080	COIL, FLTR, COIL,	OSC 85K BIAS FM DET (TOK) PCFJZH-450 L(TOK) 2.2UH(CECS) 2.2UH(CECS)
C790 C791 C792 C793 C795	87-A12-052-080 87-010-196-080 87-010-197-080 87-010-404-080 87-010-197-080	C-CAP,S CHIP CAF CAP, CHI CAP, ELE CAP, CHI	0.033-25 J B ACITOR,0.1-25 P 0.01 DM CT 4.7-50V P 0.01 DM	L951 R131 R131 R132 R132	8A-NF8-667-010 87-A00-258-080 87-A00-669-080 87-A00-258-080 87-A00-669-080	RES, M RES, M RES, M	AM PACK 4(TOK) 4/F 0.22-1W J <lh> 4/F 0.22-2W J RA<u> 4/F 0.22-1W J<lh> 4/F 0.22-2W J RA<u></u></lh></u></lh>
C796 C797 C798 C799 C800	87-010-197-080 87-010-405-080 87-010-197-080 87-010-407-080 87-012-369-080	CAP, ELE CAP, CHI CAP, ELE	P 0.01 DM CT 10-50V P 0.01 DM CT 33-50V 0.047-50F	R653 R654 R790 R991 R993	87-A11-144-080 87-A11-144-080 87-010-197-080 87-010-322-080 87-010-322-080	CAP, T CAP, C-CAP	TC U 0.1-50 K B TC U 0.1-50 K B CHIP 0.01 DM P,S 100P-50 CH P,S 100P-50 CH
C801 C802 C803 C804 C807	87-010-403-080 87-012-369-080 87-010-198-080 87-010-263-080 87-010-400-080	C-CAP,S CAP, CHI CAP, ELE	CT 3.3-50V 0.047-50F P 0.022 CT 100-10V CT 0.47-50V	R995 WH1 X991	87-010-322-080 87-A90-510-010 87-A70-061-010	HLDR,	P,S 100P-50 CH WIRE 2.5-9P KTAL 4.500MHZ CSA-309
C808 C809 C810 C814 C815	87-010-401-080 87-010-401-080 87-010-196-080 87-010-197-080 87-010-403-080	CAP, ELE CHIP CAP CAP, CHI	CT 1-50V CT 1-50V ACITOR,0.1-25 P 0.01 DM CT 3.3-50V	C101 C102 C103 C104 C105	87-010-196-080 87-012-369-080 87-010-374-040 87-A10-797-040 87-010-192-080	C-CAP, CAP,	CAPACITOR, 0.1-25 P,S 0.047-50F ELECT 47-10 47-35 M 5L SRM P,S 0.022-50 F
C816 C821 C823 C824 C825	87-010-403-080 87-010-405-080 87-010-177-080 87-010-405-080 87-010-596-080	CAP, ELE C-CAP,S CAP, ELE CAP, S		C107 C108 C109 C110 C111	87-010-196-080 87-010-178-080 87-012-369-080 87-010-197-080 87-010-196-080	CHIP C-CAP CAP,	CAPACITOR, 0.1-25 CAP 1000P P,S 0.047-50F CHIP 0.01 DM CAPACITOR, 0.1-25
C842 C844 C851 C852 C853	87-010-197-080 87-010-197-080 87-010-197-080 87-010-197-080 87-010-197-080	CAP, CHI CAP, CHI CAP, CHI CAP, CHI	P 0.01 DM P 0.01 DM P 0.01 DM P 0.01 DM P 0.01 DM	C113 C114 C115 C116 C117	87-010-178-080 87-010-154-080 87-010-175-080 87-010-400-040 87-016-460-080	CAP C CAP 5 CAP, F	CAP 1000P CHIP 10P 560P 3 0.47-50 P,S 0.22-16 B
C858 C859 C860 C959 C960	87-010-196-080 87-010-196-080 87-010-197-080 87-010-196-080 87-010-196-080	CHIP CAP CAP, CHI CHIP CAP	ACITOR, 0.1-25 ACITOR, 0.1-25 P 0.01 DM ACITOR, 0.1-25 ACITOR, 0.1-25	C118 C119 C120 C123 C124	87-A10-189-040 87-A10-189-040 87-012-156-080 87-010-196-080 87-010-196-080	CAP,E C-CAE CHIP	2 220-10 3 220-10 P,S 220P-50 CH CAPACITOR,0.1-25 CAPACITOR,0.1-25
C961 C963 C971 C972 C973	87-010-152-080 87-015-785-080 87-010-381-080 87-010-404-080 87-010-197-080	CHIP CAP CAP, ELE CAP, ELE	8P-50 CH ACITOR, 0.1FZ-25Z CT 330-16V CT 4.7-50V P 0.01 DM	C125 C126 C129 C210 C212	87-010-405-040 87-010-196-080 87-010-374-040 87-012-156-080 87-010-404-040	CHIP CAP, E C-CAE	3 10-50 CAPACITOR,0.1-25 3 47-10 P,S 220P-50 CH 3 4.7-50 SME
C974 C979 C982 C983 C984	87-010-197-080 87-010-322-080 87-010-196-080 87-010-197-080 87-010-197-080	C-CAP,S CHIP CAF CAP, CHI	P 0.01 DM 100P-50 CH ACITOR,0.1-25 P 0.01 DM P 0.01 DM	C213 C701 CN101 CN701	87-010-404-040 87-010-384-040 87-099-720-010 87-A60-673-010	CAP, E CAP, E CONN,	E 4.7-50 SME E 100-25 SME 30P TYK-B(P) 9P H 2MM JMT

REF. N	O. PART NO.	KANRI	DESCRIPTION	REF. NO	. PART NO.	KANRI	DESCRIPTION
		NO.				NO.	
CN801	87-099-015-010	, .	3P 6216V	PT C.B			
FL201	8A-NFA-604-010	, .	3T-224GNK				
L101	87-A50-050-010		JK 4.19M(COI)	C1	87-010-387-080	. ,	70-25 SME <lh></lh>
LED101	87-A40-317-080		R-342VCT31 RED	C31	87-010-403-080		ECT 3.3-50V <lh></lh>
S101	87-A91-555-010	SW,RTRY	7 EC12E24504	C184	87-010-403-080	,	ECT 3.3-50V <u></u>
				CN1	87-A61-110-010	, .	V TID-A <lh></lh>
S301	87-A90-164-080		SKQAB(N)	⚠ PT1	8A-NFA-609-010	PT,ANF-	A LH <lh></lh>
S302	87-A90-164-080	. ,	SKQAB(N)				
S303	87-A90-164-080		SKQAB(N)	⚠ PT1	8A-NFZ-610-010	,	Z U30 <u></u>
S304	87-A90-164-080	SW,TACT	SKQAB(N)	⚠ PT2	8A-NF8-673-010	PT,SUB	ANF-8 (H) KAMI <lh></lh>
S305	87-A90-164-080	SW, TACT	SKQAB(N)	₹ PT181	8A-NF8-661-010	PT,SUB	ANF-8 (U) <u></u>
				⚠ RY1	87-A91-281-010	RELAY,A	C DC12V OSA-SS-212DM5 <lh></lh>
S306	87-A90-164-080	SW, TACT	SKQAB(N)	<u> </u>	87-A90-976-010	RELAY,A	C12V SDT-S-112LMR <u></u>
S307	87-A90-164-080	SW, TACT	SKQAB(N)				
S308	87-A90-164-080	SW, TACT	SKQAB(N)	↑ S1 ↑ T1 ↑ T2	87-A90-165-010	SW,SL 1	-2-3 SWS2301 <lh></lh>
S309	87-A90-164-080	SW, TACT	SKQAB(N)	⚠ T1	87-A60-317-010	TERMINA	L, 1P MSC <lh></lh>
S321	87-A90-164-080	SW, TACT	SKQAB(N)	⚠ T2	87-A60-317-010	TERMINA	L, 1P MSC <lh></lh>
				/!\ T181	87-A60-317-010	TERMINA	L, 1P MSC <u></u>
S322	87-A90-164-080	SW, TACT	SKQAB(N)	⚠ T182	87-A60-317-010	TERMINA	L, 1P MSC <u></u>
S323	87-A90-164-080	SW, TACT	SKQAB(N)				
S324	87-A90-164-080	SW, TACT	SKQAB(N)	W99	8A-NF9-609-010	F-CABLE	,9P 2.5 480MM <u></u>
S325	87-A90-164-080	SW, TACT	SKQAB(N)	WH181	87-A90-510-010	HLDR, WI	RE 2.5-9P <u></u>
S326	87-A90-164-080	SW, TACT	SKQAB(N)				
S327	87-A90-164-080	SW, TACT	SKQAB(N)				
S328	87-A90-164-080	SW, TACT	SKQAB(N)				
S329	87-A90-164-080		SKOAB(N)				
S330	87-A90-164-080	SW, TACI	SKOAB(N)				
S331	87-A90-164-080	,	SKOAB(N)				
		,	~				
SFR701	87-024-431-080	SFR,3.3	K RH063EC				

〇チップ抵抗部品コード/CHIP RESISTOR PART CODE

チップ抵抗部品コードの成り立ち Chip Resistor Part Coding___






チップ抵抗 Chip resistor

容量	種類	許容誤差	記号	寸法/Dime	寸法/Dimensions (mm)				
Wattage	Type	Tolerance	Symbol	外形/Form	L	W	t	Resistor Code : A	
1/16W	1005	± 5%	CJ		1.0	0.5	0.35	104	
1/16W	1608	± 5%	CJ	L J t	1.6	0.8	0.45	108	
1/10W	2125	± 5%	CJ		2	1.25	0.45	118	
1/8W	3216	± 5%	CJ	r r	3.2	1.6	0.55	128	


TRANSISTOR ILLUSTRATION



CSA952 CSC4115 KTA1266 KTC3198 KTC3199




2SJ460 2SK2541




ЕСВ

DTC114ES



2SB1370



ВСЕ


2SC3331




2SA1235


KRA102 KRA107 2SC2714 2SC3052 KRC102 KRC104 CMBT5401


CMBT5551





16	20	9	(E		100	13	14	, Co	12	9.8	100) (T	<u></u>		. C) LES	E		8	-	3
26	p	c	d.	_	a	Û	ō	٤	4	Q	*		٢	ø	MINIZ	KMZ	G	1	l l	RANDOM	
36	ס	C	a	1	a	Q	ס	E	f	q	~		<u>ا</u>	ď	ı	1	PAGM			ţ	
46	D	C	d	1	Ð	Ú	מ	E	4	q	<u>×</u>		4	Ø	col (F)	col (L)	<u>E017</u>		-		
20	g	C	d	J	a)	O	ō	E	+	Ф	×		٦	Ø	Dp	AG	ROS		1	ļ	
99	ס	C	Q.		υ	U	Б	٤	4	q	¥		h	Ø	EON	t	(CLASSIC)	CROCK)	(POP)	SI	
76	Ö	C	d	_	a	J	б	ш	f	q	×	į	ч	ď	MONO		10.1	1	ı	1	
98	þ	U	a	١	Ð	O	ס	ш	f	q	¥	į	h	Ø		Taxaa.	ı	Į.	-	ļ	
96	þ	U	р	Ĺ	ש	O	ß	E	f	q	¥	į	h	ಹ	•	(<u>)</u> 기계	0	(FBASS/	B1	B2	(
106	1	S7		S11	SS	\$2	\$12	98	23	S10	83	88	S4	S1	_	ì	d	a,d,g	q	U	
	<u>a</u>	P2	РЭ	P4	PS	P6	Р7	P8	РЭ	P10	P11	P12	P13	P14	P15	P16	P17	P18	P19	P20	











U

Α

Р


Q

R


S


Т


U



SCHEMATIC DIAGRAM - 4 (PT)









IC BLOCK DIAGRAM


IC,M62495AFP



IC,LC72131D



IC,LA1843




IC DESCRIPTION

IC, M38B57MCH-E236FP

C, MISODS/IN	VICH-EZSUFF		
Pin No.	Pin Name	I/O	Description
1	I-SIG	I	RDS signal level A/D input. (Not used)
2	I-HOLD	I	Hold voltage level A/D input.
3	I-SW-(CD)	I	CD mecha SW A/D input.
4	I-DISH	I	CD turn-table position check A/D input.
5	I-KEY2	I	KEY2 A/D input.
6	I-KEY1	I	KEY1 A/D input.
7	I-RDS-DATA/ O-DSP-DATA	I/O	RDS data input / DSP IC data (V-CD) output. (Not used)
8	O-MOTOR	О	Deck motor supply ON/OFF output.
9	I-RMC	I	System remote control signal input. ("L"=ACTIVE)
10	RESET	Ι	System reset input. ("L"=RESET)
11	I-STEREO	I	Tuner stereo input. ("L"=STEREO)
12	O-DSC/O-PLL DATA	О	Function IC control & PLL data output.
13	VSS	-	GND.
14,15	XIN, XOUT	I/O	4.19MHz system CLK input / output.
16	VCC	-	Power supply input.
17	O-PB1	О	Deck 1/2 switch output. ("L"=PLAYBACK DECK 1)
18	O-STBY	О	Standby LED ON/OFF output. ("L"=ON)
19	O-RMT	О	REC mute output. ("H"=MUTE)
20	O-BIAS	О	Record bias ON/OFF output. ("L"=ON)
21	O-TU-ON	О	Tuner supply ON/OFF output. ("H"=ON)
22	O-CD-ON	О	CD supply ON/OFF output. ("H"= ON)
23	O-C.SHIFT	О	MICON clock shift output. ("L"=SHIFT)
24	O-CLK	О	PLL IC CLK output.
25	I-TM-BASE	I	8 Hz time base input.
26	O-CD-CLOSE	О	CD door close output.
27	O-CD-OPEN	О	CD door open output.
28	VEE	-	Power supply input for FL display.
29	O-STB(DSP)	О	DSP IC strobe output. (Not used)
30	O-KSCAN	О	Initial key scan output.
31	O-PLL-CE	О	CD PLL IC chip enable output.
32	O-CD-LED	О	CD flash window LED output.
33~42	G10~G1	О	FL grid output (G10~G1).
43	P22	О	FL segment output (P22). (Not used)
44~58	P21~P7	О	FL segment output (P21~P7).
59	PHONO/P6	I/O	PHONO diode input (Not used)/ FL segment output (P6).
60	DEMO/P5	I/O	CASINO DEMO diode input / FL segment output (P5).
61	NON-ECO/P4	I/O	ECO OFF diode input / FL segment output (P4).
	1		
62	I-TU3/P3	I/O	TU 3 diode input (Not used) / FL segment output (P3).
62	I-TU3/P3 I-TU2/P2	I/O I/O	TU 2 diode input (Not used) / FL segment output (P2).

Pin No.	Pin Name	I/O	Description
65	O-DISH-R	0	CD turn-table reverse turn output.
66	O-DISH-F	О	CD turn-table forward turn output.
67	I-SUBQ	I	Sub code-Q data input.
68	O-CD-CE	0	CD DSP chip enable output.
69	I-WRQ	I	CD WRQ input.
70	O-CLK (CD)	0	CD control clock output.
71	O-DATA (CD)	0	CD control data output.
72	I-TUNE/IFC	I	Tuner SD input / IF count input.
73	AVSS	-	GND.
74	VREF	-	Reference voltage.
75	I-DRF	I	CD DRF input.
76	I-RDS-CLK	I	RDS clock input. (Not used)
77	I-LEVEL	I	Connected to GND through a resistor.
78	O-POWER	О	SYSTEM Power ON/OFF output. ("H"=ON)
79	I-RE-VOL	I	Rotary encoder A/D input.
80	I-TP-SW	I	Deck mecha SW A/D input.



8 (14)

14)

< TUNER SECTION >

1. Clock frequency Check

Settings: • Test point: TP2(CLK)

Method : Set to AM 1710kHz and check that the test point is $2160kHz \pm 45Hz$.

2. AM VT Check

Settings: • Test point: TP1 (VT)

Method: Set to AM 1710kHz, 530kHz and check that the test point is less than 8.5V (1710kHz) and more than

0.6V (5201-Uz)

 $0.6V\ (530kHz).$

3. FM VT Check

Settings: • Test point: TP1 (VT)

Method : Set to FM 87.5MHz, 108.0MHz and check that the test point is more than 0.5V (87.5MHz) and less than

8.0V (108.0MHz).

4. AM Tracking Adjustment

Settings: • Test point: TP8(Lch), TP9(Rch)

• Adjustment location :

L951(1/3) 1000kHz

Method: Set to AM 1000kHz and adjust L951to MAX.

5. FM Tracking Check

Settings: • Test point: TP8(Lch), TP9(Rch)

Method: Set to FM 98.0MHz and check that the test point is

less than 9dBµV.

6. AM IF Adjustment

Settings: • Test point: TP8(Lch), TP9(Rch)

• Adjustment location :

L802450kHz

7. DC Balance / Mono Distortion Adjustment

Settings: • Test point: TP3, TP4 (DC Balance)

• Adjustment location: L801

• Input level : 60dBµV

Method: Set to FM 98.0MHz and adjust minimun distortion by L801 and check that the voltage between TP3

and TP4 becomes $0 \text{ V} \pm 300 \text{ mV}$.

< DECK SECTION >

8. Tape Speed Adjustment (DECK 1)

Settings: • Test tape: TTA-100

• Test point : TP8(Lch), TP9(Rch)

• Adjustment location: SFR701

Method : Play back the test tape and adjust SFR701 so that the frequency counter reads 3000Hz \pm 5Hz.

9. Head Azimuth Adjustment (DECK 1, DECK 2)

Settings: • Test tape: TTA-330

• Test point : TP8(Lch), TP9(Rch)

· Adjustment location: Head azimuth

adjustment screw

Method: Play back (FWD) the 8kHz signal of the test tape and adjust screw so that the output becomes maximum.

Next, perform on REV PLAY mode.

10. PB Frequency Response Check (DECK 1, DECK 2)

Settings: • Test tape: TTA-330

• Test point :TP8(Lch), TP9(Rch)

Method: Play back the 315Hz and 8kHz signals of the test tape and check that the output ratio of the 8kHz signal with respect to that of the 315Hz signal is

within 4dB.

11. PB Sensitivity Check (DECK 1, DECK 2)

Settings : • Test tape : TTA-200

• Test point : TP8(Lch), TP9(Rch)

Method: Play back the test tape and check that the output level of

the test point is $110 \text{mV} \pm 3.5 \text{dB}$.

12. REC/PB Frequency Response Check (DECK 1)

Settings: • Test tape: TTA-602

• Test point : TP8(Lch), TP9(Rch)

• Input signal: 1kHz / 8kHz (LINE IN)

Method: Apply a 1kHz signal and REC mode. Then adjust OSC attenuator so that the output level at the test points becomes -20VU. Record and play back the 1kHz and 8kHz signals and check that the output of the 8kHz signals is $0dB \pm 5dB$ with respect to that of the 1kHz

signal.

13. REC/PB Sensitivity Check (DECK 1)

Settings: • Test tape: TTA-602

• Test point : TP8(Lch), TP9(Rch)

• Input signal : 1kHz (LINE IN)

Method: Apply a 1kHz signal and REC mode. Then adjust OSC attenuator so that the output level at TP8, TP9 becomes 0VU. Record and play back the 1kHz signals

and check that the output is $-2dB \pm 3.5dB$.

< FRONT SECTION >

14. u-CON OSC Adjustment

Settings: • Test point: TP5(K-SCAN)

• Adjustment location: L101

Method : Insert AC plug while pressing of TUNER / BAND function key and POWER key. Adjust L101 so that the frequency across the test point is 58.350Hz ± 0.02 Hz.

MECHANICAL EXPLODED VIEW 1/1


- 26 -

MECHANICAL PARTS LIST 1/1

REF. NO	PART NO.	KANRI NO.	DESCRIPTION	REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
1	82-NF7-218-010		ASS	28	88-906-251-110	FF-CA	BLE,6P 1.25
	8A-NFZ-007-010				8A-NF8-205-010		
3	8A-NFZ-006-010	WINDOW,	CASS 1	30	8A-NFA-633-010	CONN	ASSY, 3P (PH)
4	8A-NFZ-004-010	BOX, CAS	5 2	31	8A-NFA-634-010	CONN	ASSY, 8P RPB
5	8A-NFZ-003-010	BOX, CAS	5 1	32	8A-NFA-214-010	HLDR,	PWB M ANFA
	8A-NFZ-011-010	,			8A-NFA-065-010		,RIGHT V-2 <lh></lh>
	8A-NFZ-012-010				8A-NFA-067-010		,RIGHT V-2 PL <u></u>
	8A-NFZ-051-010	,	DISP H <lh></lh>		8A-NFA-212-010		,PL LH <lh></lh>
	8A-NFZ-005-010	,	DISP U <u></u>		8A-NF9-211-010		PWB PT HI
9	86-NFZ-231-010	DMPR,70		36	8A-NF9-609-010	F-CAB	LE,9P 2.5 480MM <u></u>
10	8A-NFZ-001-010	CABI, FR	U	∧ 37	87-A80-092-010	AC CO	RD ASSY,E BLK SUN FAI <lh></lh>
	8A-NFZ-016-010	,		⚠ 37	87-A80-110-010	AC CO	RD ASSY,U SPT-2W <u></u>
12	8A-NFZ-017-010	KEY, CAS	S 2P	38	87-085-185-010	BUSHI	NG, AC CORD (E) < LH>
13	8Z-NB8-240-010	COVER,	PL	38	87-A91-422-010	BUSHI	NG, AC CORD(U) <u></u>
14	8A-NFZ-010-010	KEY, OPE		A	87-067-703-010	TAPPI	NG SCREW, BVT2+3-10
15	8A-NFZ-013-010	KEY,CD		В	87-NF4-224-010		EW,IT3B+3-8 CU
	8A-NFZ-009-010	,			87-067-581-010		NG SCREW, BVT2+3-15
17	8A-NFA-018-010			D	87-078-191-010		EW,IT+4-10
	8A-NFZ-008-010	,			87-067-688-010		
19	87-CE3-023-010	BADGE, A	IWA 30N SILV	F	87-723-096-410	QT2+3	-10W/O SLOT BL
	8A-NFZ-002-010				87-721-096-410		-10 GLD
	8A-NFA-208-010	,	L 100-25 ANFA		87-721-097-410	~	-12 GLD
	88-913-221-110		E, 13P 1.25 220MM		87-067-641-010		3-8(W/O SLOT)BL
	8A-NFA-062-010		OP V-2 <lh></lh>	J	87-067-579-010	TAPPI	NG SCREW, BVT2+3-8
23	8A-NFA-061-010	PANEL, TO	OP V-2 R <u></u>				
	8A-NFZ-015-010		TOP BL <u></u>				
	8A-NFA-063-010	,					
	84-ZG1-245-210						
	8A-NFZ-023-010		AR LHSM <lh></lh>				
27	8A-NFZ-021-010	CABI, RE	AR USM <u></u>				

COLOR NAME TABLE

Basic color symbol	Color	Basic color symbol	Color	Basic color symbol	Color
В	Black	С	Cream	D	Orange
G	Green	Н	Gray	L	Blue
LT	Transparent Blue	N	Gold	Р	Pink
R	Red	S	Silver	ST	Titan Silver
Т	Brown	V	Violet	W	White
WT	Transparent White	Y	Yellow	YT	Transparent Yellow
LM	Metallic Blue	LL	Light Blue	GT	Transparent Green
LD	Dark Blue	DT	Transparent Orange	GM	Metallic Green
YM	Metallic Yellow	DM	Metallic Orange		




TAPE MECHANISM PARTS LIST 1 / 1

REF. NO.	PART NO.	KANRI NO.	DESCRIPTION	REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
1	8Z-ZM1-254-210	SPR-C.	REEL R	36	8Z-ZM1-220-110	LEVER, RE	C SENSOR
	8Z-ZM1-225-110				8Z-ZM1-249-010		
	8Z-ZM1-253-110	,	AUTO SENSOR		8Z-ZM1-242-110		
	8Z-ZM1-217-110				8Z-ZM1-229-010		
	8Z-ZM1-217-110				8Z-ZM1-232-010		
5	02 201 212 110	DEVER,	1 01	40	02 201 252 010	ODAK, IDI	11/100
6	8Z-ZM1-245-010			41	8Z-ZM1-234-010	FLY-WHL,	ZZM-1
	8Z-ZM1-236-010	CLR,SL	IP FF/REW	42	8Z-ZM1-267-010	SHAFT, CA	APSTAN 2
8	8Z-ZM1-252-010	SPR-C,	FF/REW	43	8Z-ZM1-228-010	GEAR, SLI	P T-UP B
9	8Z-ZM1-230-010	GEAR, S	LIP FF/REW A	44	8Z-ZM1-265-010	FELT, T-U	JP
10	8Z-ZM1-269-010	FELT, F	F/REW 2	45	8Z-ZM1-227-010	GEAR, SLI	P T-UP A
		,	,			•	
11	8Z-ZM1-238-110	GEAR, S	LIP FF/REW B 2	46	8Z-ZM1-251-110	SPR-C, T-	UP SLIP
12	8Z-ZM1-237-010	LEVER,	FF/REW 2	47	8Z-ZM1-243-210	SPR-T,SI	COP/PAUSE
13	8Z-ZM1-209-210	LEVER,	PAUSE	48	87-A91-532-010	MOT, MS15	U2LW1A
14	8Z-ZM1-218-110	LEVER,	E-LOCK H	49	8Z-ZM1-235-010	PULLEY, N	TOT
15	8Z-ZM1-256-010			50	8Z-ZM2-216-010	BELT, MAI	N M
		•				•	
16	8Z-ZM1-244-010	SPR-T,	T-UP	51	8Z-ZM1-260-010	SPR-P,CA	ASETTE
17	8Z-ZM1-247-210	SPR-T,	PINCH	52	8Z-ZM2-201-010	CHAS ASS	SY,ZZM-2
18	8Z-ZM1-261-110	ROLLER	ASSY, PINCH	53	8Z-ZM1-255-110	SPR-T,E-	LOCK
19	8Z-ZM1-221-010	LEVER,	PINCH	54	8Z-ZM2-219-010	LEVER, E-	OPEN ZZM-2
	8Z-ZM1-205-210				8Z-ZM1-214-110		
		,				,	
21	8Z-ZM1-248-110	SPR-T,	BRG	56	8Z-ZM2-211-010	FLY-WHL,	ZZM-2
22	87-A90-403-110	HEAD, R	PH MS15R	57	8Z-ZM1-257-110	SPR-C,F/	'R
23	84-ZM2-227-310	SPR-C,	AZIMUTH	58	8Z-ZM1-275-010	W-L,1.47	7-4-0.25
24	8Z-ZM1-216-010	LEVER,	AUTO	59	80-ZM6-243-010	SH 1.75-	3.6-0.5 SLT
25	8Z-ZM1-246-010	SPR-T,	AUTO 2	60	87-A91-494-010	SW, LEAF	MSW17820
		,				,	
26	8Z-ZM2-214-010	GEAR, I	DL REW ZZM-2	61	8Z-ZM1-241-010	SPR-T, PI	AY
27	8Z-ZM2-212-010	LEVER,	STOP ZZM-2	62	8Z-ZM2-601-010	CONN ASS	SY,9P ZZM-2
28	8Z-ZM1-207-010	LEVER,	FF	A	84-ZM2-242-010		AZ1-2-6.4
	8Z-ZM1-206-010				8Z-ZM2-220-110		
	8Z-ZM1-210-010			_			
5.5							
31	87-A90-404-010	HEAD, E	H LE15B				
32	8Z-ZM2-218-010	LEVER,	REC LOCK ZZM-2				
	87-A91-492-010		F MSW18560				
	8Z-ZM1-226-010						
	8Z-ZM1-241-010	SPR-T,					

SPEAKER DISASSEMBLY INSTRUCTIONS


Type.1

Insert a flat-bladed screwdriver into the position indicated by the arrows and remove the panel. Remove the screws of each speaker unit and then remove the speaker units.




Type.2

Remove the grill frame and four pieces of rubber caps by pulling out with a flat-bladed screwdriver. Remove the screws from hole where installed rubber caps. Insert a flat-bladed screwdriver into the position indicated by the arrows and remove the panel. Remove the screws of each speaker unit and then remove the speaker units.




Type.3

Insert a flat-bladed screwdriver into the position indicated by the arrows and remove the panel. Turn the speaker unit to counter-clockwise direction while inserting a flat-bladed screwdriver into one of the hollows around speaker unit, and then remove the speaker unit. After replacing the speaker unit, install it turning to clockwise direction until "click" sound comes out.



Type.4




TOOLS

- 1 Plastic head hammer
- ② (⊖) flat head screwdriver
- 3) Cut chisel

How to Remove the PANEL, FR

- Insert the (⊖) flat head screwdriver tip into the gap between the PANEL, FR and the PANEL, SPKR. Tap the head of the (⊖) flat head screwdriver with the plastic hammer head, and create the clearance as shown in Fig-1.
- Insert the cut chisel in the clearance, and tap the head of the cut chisel with plastic hammer as shown in Fig-2, to remove the PANEL, FR.
- Place the speaker horizontally. Tap head of the cut chisel with plastic hammer as shown in Fig-3, and remove the PANEL, FR completely.



How to Attach the PANEL, FR

Attach the PANEL, FR to the PANEL, SPKR. Tap the four corners of the PANEL, FR with the plastic hammer to fit the PANEL, FR into the PANEL, SPKR completely.

SPEAKER PARTS LIST (SX-NBL17YLSC9/SX-NAJ17YUSL)

REF. NO.	PART NO.	KANRI	DESCRIPTION
		NO.	
1	8A-NSB-001-010	PANEL	, FR
2	8A-NSB-003-010	GRILL	E, FRAME ASSY
3	8Z-NSL-603-010	SPKR,	W 120 <yusl></yusl>
3	8A-NSL-602-010	SPKR,	120 <ylsc9></ylsc9>
4	87-NS7-611-010	CORD,	SPKR

ACCESSORIES / PACKAGE LIST

REF. NO.	PART NO.	KANRI	DESCRIPT	ON
		NO.		
1	8A-NFZ-902-010	IB,L	H(ESP)M -BL1	14 <lh></lh>
1	8A-NFZ-903-010	IB,U	(ESF)M -AJ17	7 <u></u>
2	8Z-NF9-701-210	RC UI	NIT,ZAS02	
3	87-043-115-010	ANT,	FEEDER FM	
4	87-006-225-010	AM LO	OOP ANT NC2	
<u> </u>	87-A91-017-010	PLUG	, CONVERSION	JT-0476 <lh></lh>

アイワ株式会社 〒110-8710 東京都台東区池之端1-2-11 ☎03(3827)3111 (代表) **AIWA CO.,LTD.** 2-11, IKENOHATA 1-CHOME, TAITO-KU, TOKYO 110, JAPAN TEL:03 (3827) 3111 9630472 0251431 Printed in Singapore